

Assembly Guide FLOOR MOUNTED/TABLE MOUNTED STEMS

REFER TO ASSEMBLY GUIDES FOR BLOOM ASSEMBLIES

Suitable For Indoor Use Only

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons to avoid a hazard.

Ta: 25°C

ENSURE POWER PLUG IS DISCONNECTED FROM POWER SUPPLY.




Figure 1




Figure 2




Figure 3

Note: Two person assembly is recommended.

FIRST STEP:

With assistance, guide the bottom of the Stem Assembly and power cable through the two supporting rings on the Base Rod.
Figures 1 and 2.

SECOND STEP:

Turn the Stem Assembly until the tongue on the supporting ring slides into the slot on the Base Rod supporting ring.
Figure 3.

Caution: Grip and lift the Rod Assembly at the Base when moving the Floor or Table Mounted Blooms to prevent the Stem from disengaging from the Base. Alternatively, remove the Bloom from the Stem, then the Stem from the Base Assembly.